
Table of contents

General information

Locking and unlocking

Seat and seatbelts

Instruments and controls

Starting and driving

For pleasant driving

Vehicle care

For emergencies


Maintenance

Specifications

Overview — Instruments and controls

EB21AOBd

- 1 - Driver's air bag* → P.67
- 2 - Combination switch (headlights, turn-signal, etc.) → P.87
- 3 - Headlight washer switch* → P.88
- 4 - Auto-speed (cruise) control - Main switch* → P.139
- 5 - Front fog lamp switch* → P.93
- 6 - Meter and gauges → P.72
- 7 - Ignition switch → P.101
- 8 - Windscreen wiper and washer switch/Rear window wiper and washer switch* → P.89, 90
- 9 - Hazard warning flasher switch → P.91
- 10 - Rear window demister switch* → P.92
- 11 - Electronic compass* → P.77
- 12 - Thermometer* → P.74
- 13 - Inclinator* → P.75
- 14 - Altimeter* → P.76
- 15 - Clock* → P.189
- 16 - Front heater/air conditioner control panel* → P.170, 175
- 17 - Radio* → P.148
- 18 - Front passenger's air bag* → P.67
- 19 - Accessory socket → P.189
- 20 - Rear differential lock switch* → P.123
- 21 - Transfer shift lever → P.113, 117
- 22 - Mechanical winch* → P.195
- 23 - Gearshift lever (M/T only) → P.105
- 24 - A/T mode changeover switch (2800A/T, 3500A/T) → P.110
- 25 - Cigarette lighter → P.187
- 26 - Rear heater/air conditioner switch* - for front seat → P.180, 183
- 27 - 3-mode variable shock absorber changeover switch* → P.144
- 28 - Rear heater/air conditioner control panel* - for second seat → P.180, 185
- 29 - Selector lever (A/T only) → P.108
- 30 - Parking brake lever → P.131
- 31 - Overdrive control switch (A/T only) → P.110
- 32 - Engine rpm adjusting knob* → P.105
- 33 - Motor antenna switch* → P.168
- 34 - Rheostat (meter illumination control)* → P.93
- 35 - Electric remote-controlled outside rear-view mirrors* → P.139
- 36 - Auto-speed (cruise) control lever* → P.139




B21A167

Indication of applicability

EB21C-A

Optional equipment marked with "*" may differ according to the country. It is sold in or the sales classification; refer to the sales catalogue.




- 1 - Rear shelf* → P.193
- 2 - Cargo lamp* → P.94
- 3 - Rear accessory socket* → P.193
- 4 - Second seat* → P.42
- 5 - Ashtray (for second seats) → P.188
- 6 - Front seat belt* → P.58
- 7 - Front seat → P.36
- 8 - Sunshade* → P.23
- 9 - Room lamp → P.94
- 10 - Spot lamp* → P.94
- 11 - Electric sunroof control switch* → P.22
- 12 - Inside rear view mirror → P.138
- 13 - Sun visor → P.186
- 14 - Electric window control switch* - main switch → P.17
- 15 - Glove box → P.190
- 16 - Tray (under front passenger's seat)* → P.192
- 17 - Ashtray (for front seats) → P.188
- 18 - Centre console box* → P.191
- 19 - Second seat belt* → P.59, 60
- 20 - Side seatback* → P.45
- 21 - Luggage securing hooks → P.195
- 22 - Inspection lamp* → P.192
- 23 - Tool box → P.216



Interior

EB2180Bb

- 1 - Cargo lamp → P.94
- 2 - Side seatback* → P.45
- 3 - Electric window control switch* → P.17
- 4 - Ashtray (for second seats) → P.188
- 5 - Sunshade* → P.24
- 6 - Spot lamp* → P.94
- 7 - Electric sunroof control switch* → P.22
- 8 - Tilt-up sunroof knob* → P.19
- 9 - Electric window control switch - main switch* → P.17
- 10 - Room lamp → P.94
- 11 - Inside rear view mirror → P.138
- 12 - Sun visor → P.186
- 13 - Glove box → P.190
- 14 - Tray (under front passenger's seat)* → P.192
- 15 - Ashtray (for front seats) → P.188
- 16 - Centre console box* → P.191
- 17 - Front seat → P.36
- 18 - Front seat belt* → P.58
- 19 - Jack storage space → P.216
- 20 - Second seat* → P.42
- 21 - Second seat belt* → P.59, 60
- 22 - Third seat* → P.47
- 23 - Luggage securing hooks → P.195
- 24 - Third seat belt* → P.59, 60
- 25 - Tool box → P.216



B21B164



- 1 - Spare wheel → P.224
- 2 - Outside rear-view mirrors → P.139
- 3 - Locking and unlocking → P.10
- 4 - Fuel filler → P.98
- 5 - Backdoor → P.15
- 6 - Front fog lamps* → P.246
- 7 - Bonnet → P.14
- 8 - Engine compartment → P.278
- 9 - Headlights → P.87
- 10 - Tyre inflation pressure → P.263
- 11 - Changing tyres → P.226
- 12 - Wheel rotation → P.264
- 13 - Tyre chains → P.265
- 14 - Canvas top* → P.27
- 15 - Mechanical winch* → P.195

GENERAL INFORMATION

Installation of accessories

EB24A-Ab

Before fitting any accessories, please consult your authorized Mitsubishi dealer.

- (1) The installation of accessories, optional parts, etc, should only be carried out within the limits prescribed by law in your country, and in accordance with the guidelines and warnings contained within the documents accompanying this vehicle.
Only Mitsubishi approved accessories should be fitted to your vehicle.
- (2) Improper installation of electrical parts could cause a fire, please refer to the Modification/Alteration to the electrical or fuel systems section within this manual.
- (3) When using a communication system such as a cellular phone or a radio set inside the vehicle, be sure to install a separate external antenna. When a cellular phone or a radio set is used by using an internal antenna alone, it will cause a failure to the vehicle's electrical system and will throw hindrance to safe operation of the vehicle, incurring a danger.

- (4) Tyres and wheels which do not meet specifications must not be used.

Refer to the "Specifications" section for information regarding wheel and tyre sizes.

Modification/alterations to the electrical or fuel systems

EB11A-A

MITSUBISHI has always offered safe, high quality vehicles. In order to maintain this safety and quality, it is important that any accessory that may be fitted, or modifications that may be carried out which involve the electrical or fuel systems, should be carried out in accordance with MITSUBISHI guidelines.

Please consult an authorized MITSUBISHI dealer concerning any such fitment or modification, as improper installation of electrical or fuel related parts could cause a fire.

Genuine parts

EB05A-Fb

Don't play around with substitutes. MITSUBISHI has gone to great lengths to bring you a superbly crafted vehicle offering the highest quality and dependability. Don't reduce that quality and dependability by using substitute parts.

Always use MITSUBISHI Genuine Parts designed and manufactured to maintain your MITSUBISHI vehicle at top performance. Failure to use Genuine Parts, may invalidate any future warranty claim.

MITSUBISHI will not be liable for any malfunction of your vehicle that may have been caused by the use of substitute parts in place of MITSUBISHI Genuine Parts.

MITSUBISHI Genuine Parts are identified by this mark, and are available at all authorized MITSUBISHI dealers.



MITSUBISHI MOTORS
GENUINE PARTS

GENERAL INFORMATION

Used engine oils safety instructions

EB12A-C



WARNING

- (1) Prolonged and repeated contact may cause serious skin disorders, including dermatitis and cancer.
- (2) Avoid contact with the skin as far as possible and wash thoroughly after any contact.
- (3) Keep out of reach of children.

Safe driving techniques

EB26A-F

Driving safety and protection against injury cannot be fully ensured. However, we recommend that you give extra attention to the following:

- (1) Before starting the vehicle, make certain that you and your passengers have fastened the seat belts.
- (2) Never leave your vehicle unattended with the key in the ignition and children inside the vehicle. Children may play with the driving controls and this could lead to an accident.
- (3) Make sure that infants and small children are properly restrained in accordance with the laws and

regulations, and for maximum protection in case of an accident.

- (4) Be sure to stop the engine if you stop for a short sleep. If the engine is left running while you sleep, unexpected vehicle starting or other accidents may be caused by unconsciously moving the shift lever (selector lever on automatic transmission vehicles) or pressing the accelerator pedal. If you unconsciously keep the accelerator pedal pressed, the engine may overheat or the engine, exhaust pipe, etc. may be abnormally overheated, resulting in an accidental fire. If poorly ventilated, there is a risk of poisoning by exhaust gas.
- (5) Keep children from playing in the luggage compartment. It's quite dangerous to allow them to play there while the vehicle is in operation.
- (6) When loading luggage, be careful not to load above the height of second or third seats. This is dangerous not only because the rear sight will be obstructed, but also the luggage may fly into the passenger's room at hard braking.

Driving and alcohol

EB25A-A

Drunken driving is one of the most frequent causes of accidents.

Your driving ability can be seriously impaired with blood alcohol levels far below the legal minimum. If you are drinking, don't drive. Ride with a designated non-drinking driver, call a cab, a friend, or use public transportation.



WARNING

Driving after drinking can lead to an accident. Your perceptions are less sharp, your reflexes are slower, and your judgement is impaired when you have been drinking. **NEVER DRINK AND THEN DRIVE**

Indication of applicability

EB21C-A

Optional equipment marked with "*" may differ according to the country. It is sold in or the sales classification; refer to the sales catalogue.

