

ALPHABETICAL INDEX

- | | | | |
|---|-------------------------|--------------------------------------|---------------|
| Accessory (Installation) | 6 | Parking brake | 131, 266 |
| Accessory boxes | 190 | Pedal free play | 266 |
| Accessory socket | 189 | Warning lamp | 82, 83, 134 |
| Additional equipment | 267 | | |
| Air conditioner | | Canvas top | |
| Air conditioner | 175 | Mounting | 33 |
| Rear air conditioner | 183 | Rear flap | 28 |
| Altimeter | 76 | Removal | 30 |
| Antenna (Motor antenna) | 168 | Side flaps | 29 |
| Antenna (Pillar antenna) | 167 | Storage | 32 |
| Anti-lock brake system (A.B.S.) | 133 | Capacities | 278, 279, 280 |
| Ashtray | 188 | Cargo lamp | 94, 250 |
| Audio system | 148, 149, 153, 158, 165 | CD (Compact-Disc) player | 165 |
| Auto-speed (cruise) control | 139 | Central door locks | 13 |
| Automatic transmission | | Centre caps | 230 |
| Fluid | 257, 279 | Changing a fuse | 240 |
| Indication lamp | 82, 108 | Charge warning lamp | 82, 86 |
| Mode changeover switch | 110 | Chassis number | 270 |
| Overdrive control switch | 110 | Check engine indication lamp | 82, 84 |
| Overdrive off indication lamp | 82, 110 | Child restraint | 61 |
| Possible driving speed | 111 | "Child-protection" rear doors | 12 |
| Selector positions | 109 | Cigarette lighter | 187 |
| Towing | 230 | Cleaning the inside of your vehicle | |
| Warning lamp | 82, 85 | Genuine leather | 206 |
| Back door | 15 | Plastic, vinyl leather, etc | 206 |
| Battery | | Upholstery | 206 |
| Checking battery | 259 | Cleaning the outside of your vehicle | |
| Discharged battery (Emergency starting) | 235 | Aluminium wheels | 210 |
| Bleeding the fuel system | 233 | Canvas top | 210 |
| Bonnet | 14 | Chrome parts | 210 |
| Brake system | | Damaged paint | 209 |
| Anti-lock brake | 133 | Polishing | 209 |
| Braking | 132 | Servicing of plastic parts | 209 |
| Fluid | 260, 279 | Sunroof | 210 |
| | | Washing | 207 |

ALPHABETICAL INDEX

- Waxing 208
- Clock (Digital) 189
- Clutch
 - Fluid 259, 279
 - Pedal free play 266
- Combination headlights, dipper and turn-signal lever 87
- Coolant (Engine) 257, 279
- Correct four-wheel drive operation 128
- Demister (Rear window) 92
- Diesel preheat indication lamp 82, 85
- Digital clock 189
- Dimensions (Specifications) 272
- Dipper (High/Low beam change) 87
- Doors
 - Back door 15
 - Central door locks 13
 - "Child protection" rear doors 12
 - Door ajar warning lamp 82, 84
 - Door lamps 250
 - Doors 10
 - Lock and unlock the doors 10
- Driving and alcohol 7
- Economical driving 100
- Electric remote-controlled outside rear-view mirrors 139
- Electric sunroof 22
- Electric window control 17
- Electrical system (Specifications) 277
- Electronic compass 77
- Emergency starting 235
- Engine
 - Coolant 257, 279
 - Indication lamp 82, 84
 - Number 270
 - Oil 254, 279, 280
 - rpm adjustment knob 105
 - Specifications 275
 - Starting the engine 102
 - Used oil safety instructions 7
- Engine overheating 232
- Exterior and interior lamp operation 265
- 4WD
 - 2WD/4WD indication lamp 82, 113, 114, 117, 118
 - Correct four-wheel drive operation 128
 - Free-wheeling hubs 121
 - Part time 4WD 117
 - Rear differential lock 123
 - Super select 4WD 113
- Fluid
 - Automatic transmission fluid 257, 279
 - Brake fluid 260, 279
 - Clutch fluid 261, 279
 - Power steering fluid 261, 280
 - Washer fluid 262
- Free-wheeling hubs
 - Automatic free-wheeling hubs 122
 - Manual free-wheeling hubs 122
- Front fog lamp switch 93
- Front seat adjustment 36
- Fuel
 - Bleeding the fuel system 233
 - Capacity (Fuel usage) 97
 - Cetane rating (Fuel usage) 97
 - Fuel filter warning lamp 82, 86
 - Fuel gauge 74
 - Low fuel warning lamp 82, 84
 - Octane rating (Fuel usage) 97
 - Refueling 98

ALPHABETICAL INDEX

- Removal of water from the fuel filter 234
- Spare fuel tank 99
- Fuses
 - Changing a fuse 240
 - Fuse load capacity 239
 - Fuses (Fuse housing locations) 238
- Gauges
 - Fuel 74
 - Water temperature 74
- Genuine parts 6
- Hazard warning flasher switch 91
- Hazard warning indication lamp 82, 83
- Headlights
 - Bulb capacity, replacement 241
 - Dipper, Passing (Headlight flasher) 87
 - Headlight washer switch 88
 - Light monitor system 87
- Headrests 57
- Heater
 - Heater 170
 - Rear heater 180
- High-beam indication lamp 82, 83
- Hinges and latches lubrication 267
- Horn switch 93
- How to store seat belts 63
- If a tyre is punctured 226
- If the vehicle breaks down 214
- Ignition switch 101
- Inclinometer 75
- Indication and warning lamps
 - 2WD/4WD indication lamp 82, 113, 114, 117, 118
 - 3-mode variable shock absorber indicator lamp 82, 144
- A/T (Automatic transmission) warning lamp 82, 85
- Anti-lock brake failure warning lamp 82, 134
- Automatic transmission indication lamp 82, 108
- Brake warning lamp 82, 83
- Charge warning lamp 82, 86
- Check engine indication lamp 82, 84
- Cruise control indication lamp 82, 140
- Diesel preheat indication lamp 82, 85
- Door-ajar warning lamp 82, 84
- Fuel filter warning lamp 82, 86
- Hazard warning indication lamp 82, 83
- High-beam indication lamp 82, 83
- Low fuel warning lamp 82, 84
- Oil pressure warning lamp 82, 84
- Overdrive off indication lamp 82, 110
- PWR/HOLD indication lamp 82, 111
- Rear differential lock indication lamp 124
- Rear window demister indication lamp 92
- Turn-signal indication lamps 82, 83
- Indication of applicability 7
- Inside rear-view mirror 138
- Inspection lamp 192, 250
- Installation of accessories 6
- Instruments 72
- Jack and jack handle 217, 219
- Jacking up the vehicle 220
- Jump starting (Emergency starting) 235
- Keys 10
- Keyless entry system 12
- Leakage (Fuel, engine coolant, oil and exhaust gas) 265
- Light monitor system 87

ALPHABETICAL INDEX

- Lights and lamps 242
 - Bulb capacity 242
 - Cargo lamp 94, 250
 - Door lamps 250
 - Exterior and interior lamp operation 265
 - Front combination lamps 244
 - Headlights 87, 243
 - High-mounted stop lamp 250
 - Inspection lamp 192, 251
 - Licence-plate lamps 248
 - Rear combination lamps 247
 - Replacement of lamp bulbs 241
 - Room lamps 94, 248
 - Side turn-signal lamps 245
 - Spot lamps 249
- Limited-slip differential 136
- Low fuel warning lamp 82, 84
- Luggage securing hooks 195
- Making a flat seat 50
- Manual transmission
 - Changing gears 106
 - Economical driving speed 106
 - Possible driving speed 107
 - Towing 230
- Manual window control 17
- Mechanical winch 195
- Meter, gauge and indication/warning lamp operation 265
- Meters
 - Altimeter 76
 - Electronic compass 77
 - Inclinometer 75
 - Odometer/Tripmeter 73
 - Rheostat (Meter illumination control) 93
 - Speedometer 73
- Tachometer 73
- Thermometer 74
- Tripmeter 73
- Mirrors
 - Electric remote-controlled outside rear-view mirrors 139
 - Inside rear-view mirror 138
 - Vanity mirror 187
- Modification/alterations to the electrical or fuel systems 6
- Motor antenna 168
- Odometer/Tripmeter 73
- Oil (Engine oil) 254, 279, 280
- Oil pressure warning lamp 82, 84
- Operation under adverse driving conditions 214
- Other specifications 277
- Outside rear-view mirrors 138
- Overheating (Engine) 232
- Parking 132
- Parking brake 131
- Parking brake lever stroke 266
- Part time 4WD 117
- Passing light (Headlight flasher) 87
- Performance (Specifications) 274
- Pillar antenna 167
- Polishing 209
- Power Steering
 - Fluid 261, 280
 - System 137
- Pregnant women restraint 63
- Puncture 226
- Radio
 - AM electronic tuning radio 148
 - AM/FM electronic tuning radio 153

ALPHABETICAL INDEX

AM/FM electronic tuning radio & cassette stereo	158	Pregnant women restraint	63
FM/SW/MW electronic tuning radio & cassette stereo	149	Seat belts	58
Rear air conditioner	183	Second seat	42
Rear differential lock		Selection of engine oil	256
Effective use of rear differential lock	126	Shock absorber	144
Incorrect use of rear differential lock	127	Sliding window	19
Operating rear differential lock	124	Snow tyres	264
Rear differential lock indication lamp	124	Spare fuel tank	99
Releasing rear differential lock	125	Spare wheel	224
Rear heater	180	Specifications	269
Rear shelf	193	Dimensions	272
Rear window demister switch	92	Electrical system	277
Rear window wiper and washer switch	90	Other specifications	277
Rear-view mirrors	138	Performance	274
Refrigerant	185, 280	Weights	274
Removal of water from the fuel filter	234	Speedometer	73
Replacement of lamp bulbs	241	Starting the engine	102
Rheostat	93	Steering	
Room lamp	94, 248	Power steering fluid	261, 280
Running-in recommendations	96	Power steering system	137
Safety driving techniques	7	Steering wheel free play	265
Seat		Steering wheel height adjustment	137
Armrest	40	Sun visors	186
Flat seat	50	Sunroof	
Front seats	36	Tilt up	19
Headrests	57	Electric	22
Second seats	42	Super select 4WD	113
Side seatback	45	Supplemental restraint system (SRS)	65
Third seats	47	3-mode variable shock absorber	144
Seat belts		Tachometer	73
Child restraint	61	Thermometer	74
How to store seat belts	63	Third seat	
Inspection	63	(front facing seats)	47
		(side facing seats)	47

ALPHABETICAL INDEX

Tilt up sunroof	19	Washing	207
Tools and jack	216	Water temperature gauge	74
Towing	230	Waxing	208
Transmission/Transfer		Weatherstripping	267
Automatic transmission	108, 276	Weights (Specifications)	274
Automatic transmission fluid	257, 279	Wheel	
Manual transmission	105, 276	Condition	263
Manual transmission oil (Capacities)	279	Rotation	264
Transfer gear ratio (Specifications)	276	Window	
Transfer oil (Capacities)	279	Electric window control	17
Transmission gear ratio (Specifications)	276	Manual window control	17
Tripmeter	73	Sliding window	19
Turn signal		Windscreen wiper and washer switch	89
Indication lamps	82, 83	Wiper blades	210, 267
Turn-signal lever	87		
Turn/lane-change signals	88		
Tyre and wheels			
Puncture	226		
Size (Specifications)	277		
Snow tyres	264		
Spare wheel	224		
Tyre chains	265		
Tyre Inflation pressure	263		
Used engine oils safety instructions	7		
Vanity mirror	187		
Vehicle information code plate	271		
Ventilation slots	267		
Ventilators	168		
Warning lamps	82, 83, 84, 85, 86		
Washer fluid			
Headlight washer fluid	262		
Rear window washer fluid	262		
Windscreen washer fluid	262		